



## Installation Guide

**SR04 - Room temperature sensor only**

**SR04P - Room temperature sensor with set point adjustment**

**SR04PT - Room temperature sensor with set point adjustment, presence key (pictured)**

**SR04PST - Room temperature sensor with set point adjustment, presence key, fan speed switch)**

**SR04P MS - Room temperature sensor with set point adjustment, slide switch O/I**

**SR04 rH (Room sensor humidity/temperature)**

**SR04P rH - Room sensor humidity/temperature with set point adjustment)**

**SR04PT rH (Room sensor humidity/temperature with set point adjustment, presence key)**

**SR04P MS rH (Room sensor humidity/temperature with set point adjustment, slide switch O/I)**

### Wireless Room Temperature Sensor



Optional: occupied button, slide switch, set point, fan selector, humidity sensor

## Overview

The ILLUMRA™ Wireless Temperature sensor detects the temperature of a room and transmits to compatible HVAC and/or humidity controllers, and/or ventilation devices. Users can also adjust temperature settings manually through its optional set point dial. For use in consistently dark areas, it can be used with an optional lithium battery. Depending on the specific model, the SR04 comes equipped with an integrated temperature sensor, humidity sensor, rotary knob for set point adjustment, rotary knob for fan speed adjustment, and/or a presence button or slide switch.

### Compatible Devices

- RF Serial Box; E3X-232FP
- Ethernet Gateway; E3X-E18-XS1
- More

### Components Included

The following items are included with this product:

- A – (1) ILLUMRA Temperature Sensor
- B – (1) Square of mounting tape

### Tools Needed for Installation

- Screwdriver
- Screws (if a screw mount is desired)
- Needle-nose pliers (if you wish to change the Transmission Time)

## Installation

To install the Temperature Sensor select a method from the options below. Follow the instructions for that method. For receiver installation instructions, see appropriate installation guide(s).

### CAUTION/NOTES:

- Always follow local electrical codes when installing this device. Installation should be performed by a qualified technician.
- ILLUMRA products are intended only for use indoors, in dry locations, and with permanently installed fixtures.
- **ILLUMRA products should NOT be installed in a location where the unit will be in close proximity to the light bulb(s) or other sources of heat, such as above a ceiling hugger fixture, particularly with higher wattage loads. Installation in close proximity to light bulbs or other heat sources may subject the receiver to temperatures exceeding the operating temperature rating (see “Operating Temperature” on specifications table).**
- Installation in metallic enclosures or near large metal objects will typically reduce radio range.

SELECT 1 OF THE FOLLOWING APPLICATIONS:


### Adhesive mount

Note: If you are unsure if a desired location is suitable for the Temperature Sensor, test its functionality in that location before installation. For guidelines on choosing a location refer to the sections in these instructions entitled “Selecting the Mounting Place for Solar Energy Storage” and “Transmission Range.”


- Step 1: Peel the lining paper off of one side of the square of mounting tape (B) included.
- Step 2: Affix the exposed mounting surface squarely to the back of the Sensor.
- Step 3: Peel the lining paper off the other side of the square mounting tape.
- Step 4: Affix the exposed mounting surface squarely to the desired location.

### Screw mount


- Step 1: Remove the backplate as shown below.



- Step 2: Mount the backplate to the wall using appropriate screws (not included).



- Step 3: Snap the Sensor onto the backplate.



## Selecting the Mounting Place for Optimum Solar Energy Storage

By means of the energy-optimized EnOcean radio technology used in Wireless Temperature Sensors, the Temperature Sensor supplies itself with electric energy using a 2 cm<sup>2</sup> solar cell and can work without batteries. Without the need to supply or change batteries, the Sensors are environmentally sound and maintenance-free.

The solar-powered energy storage may need to be recharged after prolonged storage in darkness. Typically this is accomplished automatically during the first few operating hours in daylight. If the initial charging in the first operating hours is not sufficient, the sensor should reach its fully functional state in 3 to 4 days at the latest. The sensor will operate properly even in nighttime conditions after this period of time.

To make sure the Wireless Room Temperature Sensor has enough ambient light to operate, mount the product in a suitable location. When selecting the mounting place, consider the following:

- The minimum illumination of 200Ix should be guaranteed at the mounting place for at least 3 to 4 hours every day, regardless of whether this is artificial light or daylight.
- The Health and Safety at Work Act (UK) requires a minimum illumination of 500Ix for office workplaces.
- The illumination should not exceed 1000Ix in the long term.
- Mounting in any recess that is not illuminated sufficiently in the course of a day should be avoided.
- When using collimated artificial light, the angle of incidence on the solar cell should not be too steep.
- The sensors should preferably be mounted with the solar cell facing a window, but direct sunlight should be avoided. A position which occasionally receives direct sun radiation could lead the device to report false temperature information.
- Be sure that your location will not be obscured in shadow by any changes you may make to the room in the future.


### If the ambient brightness is not sufficient

The sensor is equipped with a battery holder for use in consistently unlighted areas.

Battery to be used: Lithium battery, 3.6V/1.1Ah Type LS14250 / 0.5 AA

Operating time approx. 5 to 10 years, depending on the condition and discharge rate of the battery used.

In order to change the sensor from solar to battery mode, simply put the battery into the battery holder.



## Transmission Range

The type of material used in a building is important in evaluating the transmitting range. Some guide ranges:

- Visual contacts: Typ. 30m range in passages, corridors. Up to 100m in halls
- Rigypsum walls/wood: Typ. 30m range through max. 5 walls
- Brick wall/Gas concrete: Typ. 20m range through max. 3 walls
- Reinforced concrete/ceilings: Typ. 10m range through max. 1 ceiling
- Supply blocks and lift shafts should be seen as a compartmentalisation

### Other interference sources

Other devices that also operate with high-frequency signals (e.g. computers, audio/video systems, electronic transformers and ballasts, etc.) are also sources of interference. Keep such devices at least 0.5 m away from the Temperature Sensor.

## Programming

In order to use the Wireless Room Temperature Sensor, the device must be “learned” by the receiver. This is done automatically by means of a “learn button” on the Sensor, or manually by input of the 32bit sensor ID and a special “learning procedure” between the Sensor and a receiver. The respective details are described in the corresponding documentation of the receiver. The LEARN button for the Temperature Sensor is located behind the back plate. See the section labeled “Selecting the Mounting Place for Optimum Solar Energy Storage” on the left side of this page for a picture showing how to remove the backplate and for the location of the LEARN button.

## Temperature Sensing and Signal Transmission

There are two ways the Wireless Room Temperature Sensor can communicate temperature readings to other devices:

**Event Controlled.** When the Occupancy button on the front of the Temperature Sensor is pressed, the internal microprocessor wakes up, detects a temperature, and sends a signal conveying that reading to the receiver.

**Time Controlled.** The internal microprocessor wakes up at a selected interval, collecting temperature data and sending it to the receiver. If the temperature sensed is different that the previous reading by > 2%, the signal is sent immediately upon detection. If temperature has not changed, a signal is automatically sent after the selected number of wake cycles.

### Setting the Transmission Time

The factory settings program the Wireless Room Temperature Sensor to send a new temperature signal approximately every 16 minutes (assuming no temperature change is detected sooner). How often the Sensor sends a signal has a direct impact on its energy use. Depending on the amount of light and energy available (or the desired life of a battery, if one is being used), it may be advantageous to adjust this setting.

Three variables control the transmission time: T\_Wake up, T\_Interval, and T\_Send.


**T\_Wake up.** This determines how long the unit waits between each temperature reading to wake it back up for another.

**T\_Interval.** This determines how many wake cycles the unit will perform before sending a new signal even though the temperature has not changed.

**T\_Send.** This is determined by multiplying T\_Wake up and T\_Interval together ( $T\_Wake\ up \times T\_Interval = T\_Send$ ). It is the total time between signals (assuming temperature change is not detected sooner).

To change the Transmission Time, follow these steps:

- Step 1: Remove the unit from the backplate.
- Step 2: Locate the jumpers. These are small black brackets placed over pins in the lower left corner of the Sensor (see below).
- Step 3: Use a pair of needle-nose pliers to gently lift the jumpers off the pins and replace them in the proper formation to create the desired settings (see table below). Be sure to keep any unused jumpers in a safe place.
- Step 4: Re-attach the unit to the backplate.



### Factory Settings


T\_Wake up: 100 seconds T\_Interval: 10 cycles.

(T\_Wake up 100 seconds) x (T\_Interval 10 cycles) = T\_Send: 1000 seconds or about 16 minutes.

## Specifications

		SR04PTxx
<b>Technology</b>		EnOcean, STM
<b>Transmitting Frequency</b>		315.0 MHz
<b>Antenna</b>		Type: Helix, Gain: -3dBi
<b>Transmitting Range</b>		approx 50-150 feet in buildings
<b>Temperature Detection</b>	<b>Range</b>	0°C to 40°C
	<b>Resolution</b>	0.15 K
	<b>Absolute Accuracy</b>	typ. +/-0.4K
<b>Optional Humidity Sensor</b>	<b>Range</b>	0-100% rH
	<b>Resolution</b>	0.4% rH
	<b>Absolute Accuracy</b>	+/-3% range 30%... 80%
	<b>1 Point Calibration</b>	50%
<b>Optional Set Point Adjustment P</b>	<b>Range</b>	0 to 270° angle of rotation
	<b>Resolution</b>	1.1°
<b>Rotary Switch S</b>		Number of switching steps 5 (A, 0, I, II, III)
<b>Slide Switch MS (optional with button T)</b>		Number of switching steps 2 (O/I)
<b>Measuring Value Detection</b>		Every 100 seconds
<b>Sending Interval (defaults)</b>		...every 100 seconds if changes >0.8K or >3° angle of rotation or switch step rotary switch or slide switch
		...every 1000 seconds if changes <0.8K or <3° angle of rotation
<b>Energy Generator</b>		Solar cell, internal goldcap, maintenance-free
<b>Enclosure</b>		ABS (ASA) color pure white similar to RAL 9010
<b>Protection</b>		IP20 according to EN60529
<b>Ambient Temperature</b>		-25°C to 65°C
<b>Transport</b>		-25°C to 65°C / max. 70% rH, non-condensed
<b>Weight</b>		50g

## Dimensions (measurements in mm)



Contains FCC ID: S3N-SR04XX  
Contains IC: 7953A-SR04XX

The enclosed device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (i) this device may not cause harmful interference and (ii) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications made to this equipment not expressly approved by Thermokon may void the user's authority to operate this equipment.

This device complies with Industry Canada RSS-210 Issue 7.

This device or certain aspects thereof is protected by at least one U.S. or international patent or has at least one such patent application pending.



ILLUMRA is a trademark of Ad Hoc Electronics, LLC. Other trademarks herein are the property of their respective owners.